

Glutofill WF - Filler

Cellulose reinforced gypsum filler compound for interior use. Glutofill WF gives smooth, stress-free surfaces for subsequent wallpapering and painting works.

Instructions for use:

Glutofill WF is suitable for filling cracks and holes, for widespread smoothing, for gluing and filling the joints of gypsum boards as well as for shaping and modelling.

Can be used on all mineral surfaces such as plaster, stone, concrete, aerated concrete, masonry, etc.

Not suitable for filling works on glass, plastic, wood, metal and emulsion surfaces.

Technical specifications:

Components:	Natural gypsum, methyl cellulose
Density:	approx. 0.75 g/cm ³
pH-value:	7-8
Mixing ratio:	1.8-2.0 parts by volume of powder to 1 part by volume of water (e.g. 1 kg powder with 650 ml water)
Usage:	1 kg powder for 1 m ² and a 1 mm layer thickness
Working time:	approx. 60 minutes at 20° Celsius

Surface preparation:

The surface must be dry, firm and free of release agents (dust, formwork oil, etc.). Remove old wallpapers and flaking coats of paint with *Glutosolv TA Wallpaper Remover* removes loose plaster. Prime highly absorbent, sanding and chalking surfaces with *Glutogrund LF Deeply Penetrating Primer*.

Application:

Pour clean, cold water into a container and sprinkle in *Glutofill WF*. Stir vigorously until a smooth, lump-free mortar results. Use a firmer consistency to fill cracks and holes than for widespread filling. The filling compound can be applied with a filling knife or trowel after 2 - 3 minutes maturing time. Minor unevenness can be removed using a wet sponge board before the filler has completely hardened. After the filler has completely dried out the surface can be reground.

It may be necessary to prime the improved areas or the whole surface using *Glutogrund LF Primer* to avoid uneven drying of subsequent coats of paint of improving works.

Clean tools in water immediately after use.

Storage:

Store in a dry place! Keep the containers tightly sealed!

Important information:

Please see the EU Safety Data Sheet for all safety -related data (EU-CLP)

Available sizes:

Box 1 kg Art. no. 064102074
 Bag 5 kg Art. no. 064104074
 Bag 25 kg Art. no. 064106074